

Linear Hall Effect Sensor IC


Features:

- Wide operating range 3.0~12V, -40°C ~125°C
- Flat Response to 23kHz
- High Sensitivity 9.0 mV/G
- Wide sensible magnetic field range on different supplied voltage
 ±200 Gauss on 5V supplied voltage
 ±500 Gauss on 12V supplied voltage. Low operating current 3mA
- Two package styles TO-92S/SOT-23 available.
- Built-in temperature compensated circuit to minimize temperature's effect


Functional Description:

The W138 integrates Hall sensing element, linear amplifer, sensitivity controller and emitter follower output stage. It accurately tracks extremely small change in magnetic flux density –generally too small to operate Hall effect switch.

W138 can be applied as current sensor, tooth sensor, proximity detectors and motion detectors. As sensitive monitor of magnetic flux, it can effectively measure a system's performance with negligible system loading while providing isolation from contaminated and electrically noisy environments.








ABSOLUTE MAXIMUM RATING

Supply Voltage, Vdd 14V	
Magnetic Flux Density, BUnlimited	
Output Driving Current 0.4mA	
Operating Temperature Range Ta	2
Storage Temperature Range Ts	;
Power Dissipation Pd	
TO-92S 450mW	
SOT-23 350mW	



ORDER INFORMATION (Halogen Free)

WSH138-XPAN □ (TO-92S) WSH138-XPCN □ (SOT-23) ☐ Grade	1: A Grade 2: B Grade						
ps: (TO-92S) — 1,000/bag, (SOT-23) — 3,000/reel							


Electrical Characteristics:

 $(T=+25^{\circ}C, Vdd=5.0V)$

Electrical Cilara		(1 125 C, Yuu 5.0 Y)				
Characteristic	Symbol	Test Conditions	Min	Тур	Max	Units
Supply Voltage	Vcc	_	3.0	_	12	V
Supply Current	Isupply	B=0 Gauss		3.0	5.0	mA
Quiescent Vout	V0G	B=0 G (A Grade)	2.4	2.5	2.6	V
		B=0 G (B Grade)	2.3	2.5	2.7	
Sensitivity	△Vout	B= 0 to ± 200 G	8.0	9.0	10.0	mV/G
Bandwidth	BW	_	_	23	_	kHz
Measurable Guass	MGR	Vdd=5V	_	±200	_	Guass
Range		Vdd=12V	_	±500	_	
Temperature Drift	△Vout	B=0 Gauss	_	±1.0	_	mV/°C
Output Noise	V_{Np-p}	_	_	15	_	mV

- 1.All output-voltage measurements are made with a voltmeter having an input impedance of at least $100k\Omega$
- 2. Do not apply any 'resistor load' on output pin, it will degrade IC's performance.


Application circuit:







Package Information:

TO92S:



SOT23:







Characteristic Diagrams:

